GEMS



Show Me, Tell Me

Part of your test includes a 'Show Me, Tell Me' section. This is when your examiner will ask you questions about general maintenance and safety checks on your car.

You will be asked one question from Q1-Q16 and one question from Q17-Q23.

SHOW ME

Q1 Show me/explain how you would check that the power assisted steering is working before starting a long journey.

A1 If the steering becomes heavy the system may not be working properly. Before starting a journey two simple checks can be made. Gentle pressure on the steering wheel, maintained while the engine is started, should result in a slight but noticeable movement as the system begins to operate. Alternatively, turning the steering wheel just after moving off will give an immediate indication that the power assisted steering is functioning.

Q2 Show me how you would check the parking brake for excessive wear, making sure you keep control of your vehicle.

A2 Apply footbrake firmly, demonstrate by applying parking brake so that when it is fully applied it secures itself, and is not at the end of the working travel.

Q3 Show me how you would check that the direction indicators are working.

A3 Apply the indicators or hazard warning switch and walk around the vehicle, checking the functioning of all indicators. You may need to switch the ignition on, however you should not start the engine.

Q4 Show me how you would check that the brake lights are working on this car (switch ignition on if necessary).

A4 Operate brake pedal, make use of reflections in windows, garage doors, etc, or ask someone to help. As this is now a show me question the examiner may check the brake lights for you. You may need to switch the ignition on, however you should not start the engine.

Q5 Show me how you would switch on your headlights from dipped to main beam and explain how you would know the main beam is on whilst inside the car.

A5 Move the stalk attached to the steering column forwards which will illuminate a blue warning light on the instrument panel.

Q6 Show me how you would switch on the rear fog lights and explain when you would use them. **A6** Operate the rear fog switch after switching on dipped headlights, check switch is illuminated and explain that they should only be used when visibility is reduced to 100 metres or less.

UNDER THE BONNET

Q7 Open the bonnet, identify where you would check the engine oil level and tell me how you would check that the engine has sufficient oil.

A7 Identify dipstick/oil level indicator, describe check of oil level against the full and low markers.

Q8 Open the bonnet, identify where the brake fluid reservoir is and tell me how you would check that you have a safe level of hydraulic brake fluid.

A8 Identify reservoir, check fluid level is between full and low markers.

Q9 Open the bonnet, identify where you would check the engine coolant level and tell me how you would check that the engine has the correct level.

A9 Identify full and low level markers on the tank where fitted or radiator filler cap, and describe how to top up to correct level.

Q10 Open the bonnet, identify where the windscreen washer reservoir is and tell me how you would check the windscreen washer level.

A10 Identify reservoir and explain how the washer fluid should be filled to a level that you can see.



TELL ME

Q11 Tell me how you make sure that your head restraint is correctly adjusted so it provides the best protection in the event of a crash.

A11 The head restraint should be adjusted so the rigid part of the head restraint is at least as high as the eye or top of the ears, and as close to the back of the head as comfortable.

Q12 Tell me how you would check that the brakes are working before starting a journey.

A12 Brakes should be tested as you set off by applying gentle pressure at a slow speed. Brakes should not feel spongy or slack and the vehicle should not pull to one side.

Q13 Tell me where you would find the information for the recommended tyre pressures for this car and how tyre pressures should be checked.

Å13 Check the manufacturer's guide, use a reliable tyre pressure gauge, check and adjust pressures when the tyres are cold, not forgetting the spare tyre and remembering to refit the valve caps.

Q14 Tell me how you would know if there was a problem with the anti-locking braking system. **A14** The ABS light would illuminate on the instrument panel if there is a fault.

Q15 Tell me how you would check the tyres to ensure that they have sufficient tread depth and that their general condition is safe to use on the road.

A15 Tyres should be checked to ensure that there are no cuts and bulges. They should have 1.6mm of tread depth across the central ³/₄ of the breadth of the tyre and around the entire outer circumference. This can be checked with a tyre depth gauge or the depth markers in the tyres themselves.

Q16 Tell me how you would check the headlights and tail lights are working. **A16** Operate the switch and walk around the vehicle checking that lights are illuminated.

SHOW ME on the move

Q17 Show me how you would clean the windscreen using the windscreen washer and wipers. **A17** Operate control to wash and wipe windscreen.

Q18 Show me how you would clean the rear window using the windscreen washer and wipers. **A18** Operate control to wash and wipe rear window.

- Q19 Show me how you would operate the horn.
- A19 Press on the control which is situated on the steering wheel.

Q20 Show me how you would demist the windscreen.

A20 Select the relevant control including temperature (if required) to clear windscreen.

- Q21 Show me how you would demist the rear window.
- A21 Select the relevant control to clear rear window.

Q22 Show me how you would switch on your dipped headlights.

A22 Twist the stalk attached to the steering column which will illuminate a green light on the instrument panel.

Q23 Show me how you would open and close the side window.

A23 Select the relevant control to open and close the side window.